



**CUBIEBOARD**  
<http://cubieboard.org>

## The manual of Android MF210\_3G module

Applicable to the CB1 , CB2 and CT

Website:<http://cubieboard.org/>  
Support: [support@cubitech.com](mailto:support@cubitech.com)



Version	Author	Modification	Check
V-0.1-20150415	Payne	Init version	



## Table of Contents

1.Abstract.....	4
2.Hardware requirements .....	4
3.Software requirements.....	4
4.The hardware connection .....	5
5.Power on and open the application.....	6
5.1.Open mobile network.....	6
5.2.Application interface .....	11
5.3.Realize dialing function.....	11
5.4.Implement function of send and receive information.....	12
5.5.Go to the internet.....	13
6.Common problems and solutions .....	14

## 1. Abstract

The document is using MF210 module Implement function that dial the phone , send and receive information and go to the Internet based on Cubieboard1, Cubieboard2, Cubietruck Android operating system.

## 2. Hardware requirements

- Cubieboard1 or Cubieboard2 or Cubietruck
- MF210
- Double male head USB cable , SIM card and an antenna
- A HDMI cable, a mouse, power supply, display screen

## 3. Software requirements

The Android operating system, firmware.

The firmware download address:




Cubieboard1 : android-cubieboard-3G-v1.0.img.7z

Cubieboard2 : android-cubieboard2-3G-v1.0.img.7z

Cubietruck : android-cubietruck-3G-v1.0.img.7z



## 4. The hardware connection







## 5. Power on and open the application

### 5.1. Open mobile network


(1) After System startup, click "Settings", the following figure:




(2) Shown below after click "Settings", click "more" option, the following figure:




(3) Then click on the "Mobile networks" option, in the diagram below:



(4) Then click on the “Data roaming” , in the diagram below:



(5) A "note" TAB, click "ok" ,after the diagram below:








## 5.2. Application interface




## 5.3. Realize dialing function

(1) Click "Phone", As the following interface




(2) Input the number, and click "Phone" icon, has called the diagram below




#### 5.4. Implement function of send and receive information

(1) Click "Messaging" ,As fellow:



(2) Click on the "NEW MESSAGE", and then enter the number and type information, realize the receiver information, the following figure :



## 5.5. Go to the internet

Click "Browser", input "www.baidu.com", as follow:



## 6. Common problems and solutions

1.The 3 G module can work normally?

Answer: Maybe the antenna is not good, or try other antenna, and whether a SIM card is ok.

2.Can make a phone call but cannot get to the Internet?

Answer:Check whether is open "Data roaming" .

3.Calling but other can't hear voice?

Answer:Currently only supports the answer function, because it is no MIC audio input interface for Cubieboard (temporarily does not support) .