



CUBIEBOARD
<http://cubieboard.org>

MF210_3G Module debugging

Apply to Cubieboard2



Version	Author	Modification	Check
V-0.1-20150415	Payne	Init version	



Table of Contents

1.Drive version instructions :	4
1.1.Directory structure	4
1.2.Document describing.....	5
2.Add the kernel module	5
2.1.Add the driver.....	5
2.2.Add equipment VID and PID	5
2.3.Add the PPP components	6
3.Integrated driver file	7
3.1.Integrated dial scripts.....	7
3.1.1.Copying files	7
3.1.2.Packaging file into the system	7
3.2.Modify the system configuration	9
3.2.1.Open the system voice telephone access and text messaging	9
3.2.2.To specify system rild library path.....	11
3.2.3.Modify the drive device file permissions, add rild service	12
3.2.4.Modify android_filesystem_config.h	13
3.2.5.Modify property_service.c.....	14
3.2.6.Modify ueventd.rc.....	15

1. Drive version instructions :

1.1. Directory structure

```
|----- script
|
|   |----- chat.c
|   |----- init.gprs-pppd
|   |----- ip-down-ppp0.c
|   |----- ip-up-ppp0.c
|   |----- The results of the source file compiled
|           |----- chat
|           |----- ip-down-ppp0
|           |----- ip-up-ppp0
|           |----- readme.txt
|----- so
|   |----- Android4.x
|           |----- libreference-ril.so
|----- userguide
|   |----- Android system RIL adaptation user reference -V0.8.pdf
|   |----- Additional instructions.pdf
```

1.2. Document describing

Driver version document describing

/script	Phone script
/so	To transplant the ril library
/userguide	Use the reference documents

The document instructions : The Green part is the code of increase,
the red part is reducing code.

2. Add the kernel module

2.1. Add the driver

The add of Module driven need to configure android kernel,
configuration method is as follows:

```
cd linux-3.4/  
make ARCH=arm menuconfig  
device drivers--->usb support--->usb serial converter support
```

Selected the following components :

USB driver for GSM and CDMA modems

2.2. Add equipment VID and PID

Modify the kernel source file option.c
(Path:lichee/linux-3.4/drivers/usb/serial/option.c)

```
diff --git a/drivers/usb/serial/option.c  
b/drivers/usb/serial/option.c  
index ca5dff..b6336e9 100755  
--- a/drivers/usb/serial/option.c
```



```
+++ b/drivers/usb/serial/option.c
@@ -626,6 +626,7 @@ static const struct option_blacklist_info
telit_le920_blacklist = {
};

static const struct usb_device_id option_ids[] = {
+   { USB_DEVICE(0x19d2, 0x0117) }, //by Cesc. iball 3.5G, India .
0x05c60016_0x19d20117,

    { USB_DEVICE(0x05c6, 0x0016) }, //by Cesc. iball 3.5G, India .
0x05c60016_0x05c60016,
    { USB_DEVICE(0x19d2, 0x0088) }, //by Cesc. iball 3.5G, India .
0x05c60018_0x19d20088,

    { USB_DEVICE(0x12d1, 0x151d) }, //by Cesc. E3131, orange.
12d114fe_12d1151d
```

note:

0 x19d2 for ZTE vendor ID

0 x0117 for MF210V2 device ID

The above ID to be decided according to the specific module, different module ID.

2.3.Add the PPP components

Ril drive networking layer using the PPP protocol to create a data link,so you need to support for the PPP protocol in the kernel configuration. Configuration as follows:

```
cd linux-3.4/
```

```
make ARCH=arm menuconfig
```

```
device drivers--->network device support--->ppp surport
```

Selected the following components :

```
ppp filtering
ppp support for async serial ports
ppp support for sync tty ports
ppp deflate compression
ppp BSD-compress compression
```

3. Integrated driver file

3.1. Integrated dial scripts

3.1.1. Copying files

Copy chat, ip-down-ppp0, ip-up-ppp0, libreference-ril.so into
../device/third_part/zte (need to create zte).

3.1.2. Packaging file into the system

Modify the device/softwinner/sugar-cubieboard2/sugar_cubieboard2.mk

```
diff --git a/device/softwinner/sugar-
cubieboard2/sugar_cubieboard2 .mk b/device/softwinner/sugar-
cubieboard2/sugar_cubieboard2 .mk
index 860e2d3..26493c8 100755
--- a/device/softwinner/sugar-cubieboard2/sugar_cubieboard2 .mk
+++ b/device/softwinner/sugar-cubieboard2/sugar_cubieboard2 .mk
@@ -46,10 +46,26 @@ PRODUCT_COPY_FILES += \
```



```
device/softwinner/sugar-  
cubieboard2/vold.fstab:system/etc/vold.fstab
```

```
PRODUCT_PACKAGES += \  
+ Phone \  
    TvdLauncher \  
    Bluetooth  
# TSCalibration2
```

```
+PRODUCT_PACKAGES += \  
+ ip-up-ppp0 \  
+ chat \  
+ Stk \  
+ rild \  
+ pppd \  
+ ip-down-ppp0
```

```
+PRODUCT_COPY_FILES += \  
+ device/third_part/zte/init.gprs-pppd:system/etc/init.gprs-pppd \  
+ device/third_part/zte/ip-up-ppp0:system/etc/ppp/ip-up-ppp0 \  
+ device/third_part/zte/chat:system/bin/chat \  
+ device/third_part/zte/ip-down-ppp0:system/etc/ppp/ip-down-ppp0 \  
+ device/third_part/zte/libreference-  
ril.so:system/lib/libreference-ril.so
```

```
# wifi & bt config file
```

```
PRODUCT_COPY_FILES += \  
+ device/third_part/zte/libreference-  
ril.so:system/lib/libreference-ril.so
```



```
frameworks/native/data/etc/android.hardware.wifi.xml:system/etc/permissions/android.hardware.wifi.xml \
```

note: When the system is compiled, you can find `init.gprs-pppd` in the out directory corresponding to the platform of the system/etc/ ;

you can find `ip-up-ppp0` and `ip-down-ppp0` in the out directory corresponding to the platform of the system/etc/ppp ;

you can find `libreference-ril.so` in the out directory corresponding to the platform of the system/lib ;

If the file is not found that source not packaged into the system, please check whether the related configuration is correct.

3.2. Modify the system configuration

3.2.1. Open the system voice telephone access and text messaging

```
vim device/softwinner/sugar-  
cubieboard2/overlay/frameworks/base/core/res/res/values/config.xml  
diff --git a/device/softwinner/sugar-  
cubieboard2/overlay/frameworks/base/core/res/res/values/config.xml  
b/device/softwinner/sugar- cubieboard2  
index edf0cfd..73acb6c 100755  
--- a/device/softwinner/sugar-  
cubieboard2/overlay/frameworks/base/core/res/res/values/config.xml  
+++ b/device/softwinner/sugar-  
cubieboard2/overlay/frameworks/base/core/res/res/values/config.xml  
@@ -45,7 +45,7 @@
```

PackageManager.FEATURE_TELEPHONY system feature, which is



3.2.2.To specify system rild library path

```
vim device/softwinner/wing-common/ProductCommon.mk
diff --git a/device/softwinner/wing-common/ProductCommon.mk
b/device/softwinner/wing-common/ProductCommon.mk
index 0f13874..7af799c 100755
--- a/device/softwinner/wing-common/ProductCommon.mk
+++ b/device/softwinner/wing-common/ProductCommon.mk
@@ -123,15 +123,15 @@ PRODUCT_COPY_FILES += \
PRODUCT_PROPERTY_OVERRIDES += \

ro.kernel.android.checkjni=0 \
    persist.sys.timezone=Asia/Shanghai \
    wifi.interface=wlan0 \
    wifi.supPLICANT_scan_interval=15 \
    debug.egl.hw=1 \
    ro.display.switch=1 \
    ro.opengles.version=131072 \
    rild.libargs=-d/dev/ttyUSB2 \
-    rild.libpath=/system/lib/libsoftwinner-ril.so \
+    rild.libpath=/system/lib/libreference-ril.so \
    keyguard.no_require_sim=true \
    persist.sys.strictmode.visual=0 \
    persist.sys.strictmode.disable=1 \
```



3.2.3. Modify the drive device file permissions, add rild service

```
(-d said module receives the AT port parameters of service , - u said  
DATA port)
```

```
diff --git a/device/softwinner/wing-common/init.rc  
b/device/softwinner/wing-comm
```

```
index 7f1105f..548b43c 100755
```

```
--- a/device/softwinner/wing-common/init.rc
```

```
+++ b/device/softwinner/wing-common/init.rc
```

```
@@ -437,12 +455,21 @@ service netd /system/bin/netd
```

```
service debuggerd /system/bin/debuggerd
```

```
class main
```

```
-service ril-daemon /system/bin/rild
```

```
+service ril-daemon /system/bin/rild -1 /system/lib/libreference-  
ril.so
```

```
+ -- -d /dev/ttyUSB2 -u /dev/ttyUSB1
```

```
class main
```

```
socket ril stream 660 root radio
```

```
socket ril-debug stream 660 radio system
```

```
user root
```

```
group radio cache inet misc audio sdcard_rw log
```

```
+ on property:ril.reset.rild=1
```

```
+ stop ril-daemon
```

```
+ start ril-daemon
```

```
+ setprop ril.reset.rild 0
```



```
+ on property:ril.reset.modem=1
+ /system/bin/ResetModem:
service surfaceflinger /system/bin/surfaceflinger
class main
@@ -476,6 +503,13 @@ service bootanim /system/bin/bootanimation
disabled
oneshot
+ ###-----add pppd_gprs-----###
+service pppd_gprs /system/etc/init.gprs-pppd
+ user root
+ group radio cache inet misc
+ disabled
+ oneshot
service installd /system/bin/installd
class main
socket installd stream 600 system system
```

3.2.4.Modify android_filesystem_config.h

```
diff --git a/system/core/include/private/android_filesystem_config.h
b/system/co
index 7e34da8..3d38clf 100644
--- a/system/core/include/private/android_filesystem_config.h
+++ b/system/core/include/private/android_filesystem_config.h
@@ -194,7 +194,8 @@ static struct fs_path_config android_files[] = {
    { 00550, AID_DHCP,      AID_SHELL,
```

```
"system/etc/dhccpd/dhccpd-run-hooks"
```

```
{ 00440, AID_BLUETOOTH, AID_BLUETOOTH,
```

```
"system/etc/dbus.conf" },
```

```
{ 00444, AID_RADIO, AID_AUDIO,
```

```
"system/etc/AudioPara4.csv" },
```

```
- { 00555, AID_ROOT, AID_ROOT, "system/etc/ppp/*" },
```

```
+ { 00777, AID_ROOT, AID_SHELL, "system/etc/init.gprs-pppd" },
```

```
+ { 00777, AID_ROOT, AID_ROOT, "system/etc/ppp/*" },
```

```
{ 00555, AID_ROOT, AID_ROOT, "system/etc/rc.*" },
```

```
{ 00644, AID_SYSTEM, AID_SYSTEM, "data/app/*" },
```

```
{ 00644, AID_MEDIA_RW, AID_MEDIA_RW, "data/media/*" },
```

3.2.5. Modify property_service.c

```
diff --git a/system/core/init/property_service.c
```

```
b/system/core/init/property_ser
```

```
index dfe62ed..a6cc76a 100755
```

```
--- a/system/core/init/property_service.c
```

```
+++ b/system/core/init/property_service.c
```

```
@@ -65,6 +65,7 @@ struct {
```

```
} property_perms[] = {
```

```
{ "net.rmnet0.", AID_RADIO, 0 },
```

```
{ "net.gprs.", AID_RADIO, 0 },
```

```
+ { "net.ppp0.", AID_RADIO, 0 },
```

```
{ "net.ppp", AID_RADIO, 0 },
```



```
{ "net.qmi",          AID_RADIO,    0 },
```

```
{ "ril.pcu",         AID_RADIO,    0 },
```

```
@@ -112,8 +113,9 @@ struct {
```

```
    unsigned int uid;
```

```
    unsigned int gid;
```

```
    } control_perms[] = {
```

```
-    { "dumpstate", AID_SHELL, AID_LOG },
```

```
-    { "ril-daemon", AID_RADIO, AID_RADIO },
```

```
+    { "pppd_gprs", AID_RADIO, AID_LOG },
```

```
    {NULL, 0, 0 }
```

```
};
```

3.2.6. Modify ueventd.rc

```
diff --git a/system/core/rootdir/ueventd.rc
```

```
b/system/core/rootdir/ueventd.rc
```

```
index b1664f4..c12da8d 100644
```

```
--- a/system/core/rootdir/ueventd.rc
```

```
+++ b/system/core/rootdir/ueventd.rc
```

```
@@ -7,6 +7,11 @@
```

```
/dev/urandom          0666  root  root
```

```
/dev/ashmem           0666  root  root
```

```
/dev/binder           0666  root  root
```

```
+ /dev/ttyUSB0        0660  radio radio
```



```
+/dev/ttyUSB1          0660  radio  radio
```

```
+/dev/ttyUSB2          0660  radio  radio
```

```
+/dev/ttyUSB3          0660  radio  radio
```

```
+/dev/ttyUSB4          0660  radio  radio
```

```
# Anyone can read the logs, but if they're not in the "logs"
```

```
# group, then they'll only see log entries for their UID.
```

The AT command

```
at+cgmi                To find the manufacturer name
```

```
ZTE WELINK CORPORATION
```

```
OK
```

```
at+cgmm                To find the module type
```

```
MF210V2
```

```
OK
```

```
at+csq                Returns 0 is no signal, return 28 express signals is strong(typically around 6 to normal access to the Internet)
```

```
+CSQ: 28,99
```

```
OK
```

```
atd13631286255;       Phone
```

```
OK                    Success Phone return OK
```

```
RINGBACK
```

View the RIL logs



Use logcat program to view the system log.

Logcat log output classification:

Logcat: look at all the LOG

logcat -b radio: view the system log radio module

logcat -b radio -s RILD: Check ZTEMT RIL driver log